




ROC 2015  
Reverse Osmosis  
Controller  
Product  
Catalogue


# Overview

The Controller is an automated management system specifically designed for small-scale top-notch anti-osmosis water treatment systems. By simply adding a few peripheral electrical components, it can automatically operate reverse osmosis devices. Equipped with five state digital input (DI) ports and four output control ports, this compact and cost-effective controller offers efficient water treatment solutions.

## Operating Diagram



## Basic Process Flow




## Mail Technology Parameters

Supply voltage	AC 220V±10% 50/60Hz
Power consumption	<3.5W
Environmental conditions	1) Temperature:(0~50)°C ;
	2) Humidity:≤85% RH
Load capacity of output contacts	5A/250V AC (resistive load)
Dimensions	(48×96×80)mm (height*width*depth)
Hole size	(44×92)mm(height*width)

# Main Control Functions

<p>Dry-run protection function</p>	<p>It is used to monitor water source when raw water is cut off (low level of water storage tank and the pressure of pipeline getting too low)to prevent from system idling. The controller stops the operation of whole RO system, while the indicator light on panel for "LOW FEED PRESS" lightens and buzzer sounds. After that, the controller will detect dry-run switch uninterruptedly, and if the water supply pressure or water level returns to normal, the controller will restart RO system for operation.</p>
<p>Low-pressure protection function</p>	<p>When front-end pretreatment system is in flushing or regenerating state, the security filter being dirtied and jammed, and cannot supply normal feeding pressure for RO system (namely the low pressure is insufficient) , the controller will temporally shut down the whole RO system. At this moment, the indicator light for "LOW PRESS" and the buzzer sounds.</p> <p>Then, the controller will continuously detect the low-pressure protection switch, and after the pressure recovery for 1 minute, RO control system will start at first time, and operate RO system.</p> <p>In event of low-pressure protection for system again, stop the operation of RO system. The procedure sets three times of trial running, and when they are not successful, the system will enter deadlock protection state. The indicator light for low-pressure protection is on to reminder the reason to shut down, and is waiting for restart by pressing the reset key after treatment by manpower.</p>
<p>High-pressure protection function</p>	<p>In some systems with high-pressure protection, if the system has overpressure, the controller will automatically close the whole RO system, and the indicator light for "HIGH PRESS" lights up. After elimination of high pressure for 1 minute, the controller will perform trial running at the first time. If the outlet pressure still has overpressure, the system will become into protection state again. The high-pressure protection procedure sets three times of trial running, and when they are not successful, the system will go into deadlock protection state and the buzzer sounds.</p> <p>*If the system has no high-pressure protection, short out the terminal (COM+HP)</p>
<p>Pure water tank level Control function</p>	<p>When pure water tank level is at preset low level, the controller will start RO system immediately to generate water till the level of pure water tank up to the preset high level, and the system will flush membrane completely and shift to standby state.</p>
<p>Membrane flushing function</p>	<p>When the protective device and state is normal, the system will perform membrane flushing every time power up, and then repeat it every low-level water preparing. When the water producing tank is filled, the membrane flushing will be automatically ended.</p>

# Display Panel



The display panel features 10 indicator lights, each representing the operational status of individual points.

POWER	Power-on indicator light for controller
INLET VALVE	Indicator light for start of feeding water solenoid valve
M1	Indicator light for operation of low-pressure pump
M2	Indicator light for operation of high-pressure pump
RO	Indicator light for reverse osmosis membrane modulus in water preparing state
FLUSH VALVE	Indicator light for flushing solenoid valve
FULL	Indicator light for pure water tank filling
LOW FEED PRESS	Indicator light for water low pressure or no water warning ( No water alarm when connected to the low liquid level swith of water tank in reserve)
LOW PRESS	Indicator light for low-pressure warning ( security filter and electromagnetic valve supervision)
HIGH PRESS	Indicator light for high-pressure and hyperpressure warning

# Wiring Diagram

## Back Wiring Terminal




Connection of signals collection terminals	
FS	High-pressure and low-pressure flushing selection, disconnecting in case of High-pressure, and short in case of low-pressure
HP	Access terminal for overpressure detection of Booster (high pressure) pump (normally closed, disconnecting in case of overpressure, and short out COM at top right corner when not using)
NW	Detection on low level of original water tank or low pressure of pipeline (use liquid level switch or pressure switch and installation of sampling point)
LP	Access terminal of switch for detecting security filter pressure at back of low-pressure pump(Contact normally open, and closed when up to the pressure as required)
LC	Input terminal of switch for detecting level of pure water tank (normally closed, disconnecting in case of the water full and closed meeting low liquid level)
EC	Whether the control system operates for access terminal for external control(control by remote and panel switch)
COM	Common port for upper acquisition terminal

Connection of control terminal	
AC 220V	Firewire end for 220V power supply (220V AC powers on)
	Zero line for power grid
COM	Common point for control relay
IV	Output contact for controlling on and off of water feeding solenoid valve (normally open and passive)
FV	Control contact for on and off of RO flushing solenoid valve (normally open and passive)
LM	Contact for controlling start/stop of booster pump(normally open and passive)
HM	Contact for controlling start/stop of low-pressure water pump (normally open and passive)

**\*All the above control ports are terminals of dry contact of relay (without power distribution) sharing COM common terminal\***


## Schematic diagram for input wiring



**Input Signals and COM interfaces are strictly forbidden from introducing any active signals, whether directly or indirectly.**

**The link between the signal and the COM terminal should only involve passive sensors or signals.**

# Procedure Control Flow Chart



External control starts	When master control switch or remote control switch starts, the controller performs self-check. When confirming the water tank is not full, successively open the water inlet valve, low-pressure pump, and high-pressure pump, flushing valve, starting up and supplement water to the high level.
Operation monitoring	The acquisition part of controller checks the logic state of each control switch with scanning mode, make a judgement on start/stop and protection, and ensure the system runs safely
Running protection	If water supply is insufficient during system starting or operation, it will play the role of protection. After water pressure recovery, delay trial startup, and if it still cannot continuously operate after three times of trial start, it will go into protection state, waiting for manual handling; if high-pressure pump runs beyond its limit for one second, the system will stop safely. Perform trial running every one minute for high-pressure pump. If after three times of trial running, the warning of high-pressure pump is still not clear, then store the current state, to wait for manual handling; the controller will ignore the abnormal alarm which is less than one second.
Membrane flushing	For initial power on, the system performs 30s of membrane flushing. During operation, flush for 10s for each time of starting up or water full. Automatic flushing for 10s after continuous operation for 3h or in standby for 3h after water full.
Change and extension	In application of project, when the above working modes not suitable for user, it may fax the requirements of working mode so as to modify the working procedure applicable to them.





**+27 62 375 5088**



**+27 65 321 5803**



<https://www.thewatersolarcompany.co.za/>



<https://maps.app.goo.gl/MBR2LMW3T6f9TtHV9>



<https://www.facebook.com/watersolarcompany>



<https://www.youtube.com/@TheWaterSolarCompany/>



<https://www.instagram.com/watersolarcompany2023/>